

**FITTING INSTRUCTIONS**

1. Cut aluminium to required length with a fine toothed hacksaw.
2. Use adhesive or screw fix as determined. Allow 24 hours for adhesive to fully cure before foot traffic.

**Suggested adhesives:** Selleys® Flexiseal Polyurethane Sealant, ArmourFlex, or Sikaflex® 11FC+

*Note: Hardwood floors may require pilot holes if difficult to nail or screw. Concrete will need to be drilled and plugged. Always wear eye protection.*

