

FITTING INSTRUCTIONS

RP14A - Weather Strip for Doors & Windows



DIRECTIONS FOR MODEL RP14A

All surfaces must be clean, smooth, and if painted well cured.

Note: Self-adhesive seals will not stick to oil-rub finishes.

1. Use a pin to carefully partially separate backing from adhesive.
2. Apply foam as illustrated.

