

FITTING INSTRUCTIONS

RP14B - Weather Strip for Doors & Windows



DIRECTIONS FOR MODEL RP14B

All surfaces must be clean, smooth, and if painted well cured.

Note: Self-adhesive seals will not stick to oil-rub finishes.

1. Use a pin to carefully separate backing from adhesive.
2. Apply foam as illustrated.

