

# FITTING INSTRUCTIONS

## RP48 - Door & Window Weather Strip



### DIRECTIONS FOR MODEL RP48

All surfaces must be clean, smooth, and if painted well cured.

*Note: Self-adhesive seals will not stick to oil-rub finishes.*

1. Use a pin to carefully separate backing from adhesive.
2. Separate twin rubber weather strip to form single strip.
3. Apply seal on Latch Side and Hinge Side as illustrated.

