FIX-A-LOO



HYGENIX

PREMIER SOFT CLOSE TOILET SEAT

CODE: 245496

10 YEAR WARRANTY

This warranty runs for ten years from the date of purchase.

Our products come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other loss or damage. You are also entitled to have the goods repaired if the goods fail to be of an acceptable quality and the failure does not amount to a major failure.

What is covered:

only. The warranty covers any defects in materials or workmanship with the exception of the reasons stated below.

What is not covered:

Claim procedure:

contact FIX-A-TAP Australia via our website at www.fixatap.com.au/warranty to complete the warranty claim form. Alternatively you can

Any written correspondence should be sent to:

FIX-A-TAP Australia Pty Ltd, PO Box 200, Wahroonga NSW 2076

Please keep your receipt for proof of purchase.

PLUMBCONNECT PLUMBERS REGISTRY

Need a plumber?

To find a plumber in your area, consult our PlumbConnect Registry using the QR code or via our website:



www.fixatap.com.au/find-a-plumber

This warranty covers the product for domestic use

This warranty does not cover wear and tear to working parts, misuse or abuse. It does not cover discolourations due to exposure or cleaning chemicals

If you believe you have a legitimate claim, please contact our office on 02 9476 7400.

STAINLESS STEEL HINGE **COVERS**

INSTALLATION INSTRUCTIONS

- **QUICK RELEASE BUTTON** HINGE HINGE
- 1. Press 'quick release' button to release hinges. Remove hinges from seat.
- 2. (Skip this step for bottom fixing). **PUSH RUBBER** NUTS THROUGH PAN HOLES

BOLT

HINGE RODS

UNDERSIDE

OF PAN

WASHER

BOTTOM

PLASTIC NUT

FIXING

SPHERICAL DESIGN HOLDS THE NUT FIRMLY FROM UNDERNEATH

METAL WASHER

3. Place the metal washer into the indentation on the hinges, then place the bolt through the hole.

from underneath the pan.

If you would like to top fix the seat, push the

rubber nuts through your pan holes with the

use the bolt to push the nut through the hole.

The spherical design then holds the nut firmly

wider flat side up. If struggling to push through,

- If top fixing this bolt can be fastened from above using a Philips head screwdriver.
- If bottom fixing, add the plastic washer and loosely screw on the plastic bolt from underneath the pan.
- 4. Move the hinge rods into place to align with the holes on the toilet seat. Fit seat to hinges, then adjust the positioning of the seat to the desired pan location.

If bottom fixing, tighten nuts from below.

- 5. Remove seat by pressing the 'quick release' button (as in step 1).
 - If top fixing, tighten the bolts from above with a screwdriver.

Place stainless steel covers over hinges and refit seat.

Clean with warm soapy water or a household detergent using a soft cloth or sponge. Do not use bleach or a harsh chemical based cleaner. Do not use a scourer as this may damage the finish.

MAINTENANCE CLEANING INSTRUCTIONS